

FIG.4




FIG.5

FLAG CDPWRF \ FUNCTION	BROADCAST RECEIVING	CD/CASSETTE/ LINE INPUTS (MD)
"1"	ON	ON
"0"	OFF	ON

POWER CONTROL OF CD PLAYER